A.Y. McDonald Mfg. Co. Bronze Single Strap Saddle Instructions

- 1. Whenever possible, saddles should be installed after pipe pressure testing is completed.
- 2. Make sure you have proper type and size of saddle for pipe. Reference pipe diameter range, tap size and identification located on the top piece of each saddle.

3. Do not use on PVC pipe.

- 4. Clean pipe surface thoroughly.
- 5. DO NOT use Vaseline ®, plumber's grease, or any other petroleum based product on seals or o-rings.
- Mount saddle on pipe with outlet facing 6. desired direction.

7. Tighten nuts evenly to a torque of 45-55 FOOT POUNDS.

- 8. After the corporation stop has been installed, recheck saddle torque and tighten if necessary.
- 9. A.Y. McDonald single strap saddles are designed to withstand water working pressure up to, but not exceeding, the working pressure rating of the pipe. Use only on a cold water service.
- 10. Saddle testing should be accomplished while services are exposed and prior to backfilling.

WARNING: Not for use in applications with frequent cyclic loading such as air blow off valves on water and sewer force mains. 3210-319 4/22



A.Y. McDonald Mfg. Co. Bronze Single Strap Saddle Instructions

- 1. Whenever possible, saddles should be installed after pipe pressure testing is completed.
- 2. Make sure you have proper type and size of saddle for pipe. Reference pipe diameter range, tap size and identification located on the top piece of each saddle.

3. Do not use on PVC pipe.

- 4. Clean pipe surface thoroughly.
- 5. DO NOT use Vaseline ®, plumber's grease, or any other petroleum based product on seals or o-rings.
- Mount saddle on pipe with outlet facing 6 desired direction.
- 7. Tighten nuts evenly to a torque of 45-55 FOOT POUNDS.
- 8. After the corporation stop has been installed, recheck saddle torque and tighten if necessary.
- 9. A.Y. McDonald single strap saddles are designed to withstand water working pressure up to, but not exceeding, the working pressure rating of the pipe. Use only on a cold water service.
- **10.** Saddle testing should be accomplished while services are exposed and prior to backfilling.

WARNING: Not for use in applications with frequent cyclic loading such as air blow off valves on water and sewer force mains. 3210-319 4/22



A.Y. McDonald Mfg. Co. Bronze Single Strap Saddle Instructions

- 1. Whenever possible, saddles should be installed after pipe pressure testing is completed.
- 2. Make sure you have proper type and size of saddle for pipe. Reference pipe diameter range, tap size and identification located on the top piece of each saddle.

3. Do not use on PVC pipe.

- 4. Clean pipe surface thoroughly.
- 5. DO NOT use Vaseline ®, plumber's grease, or any other petroleum based product on seals or o-rings.
- Mount saddle on pipe with outlet facing 6 desired direction.
- 7. Tighten nuts evenly to a torque of 45-55 FOOT POUNDS.
- 8. After the corporation stop has been installed, recheck saddle torque and tighten if necessary.
- 9. A.Y. McDonald single strap saddles are designed to withstand water working pressure up to, but not exceeding, the working pressure rating of the pipe. Use only on a cold water service.
- 10. Saddle testing should be accomplished while services are exposed and prior to backfilling.

WARNING: Not for use in applications with frequent cyclic loading such as air blow off valves on water and sewer force mains. 3210-319 4/22

A.Y. McDonald Mfg. Co. Bronze Single Strap Saddle Instructions

- 1. Whenever possible, saddles should be installed after pipe pressure testing is completed.
- 2. Make sure you have proper type and size of saddle for pipe. Reference pipe diameter range, tap size and identification located on the top piece of each saddle.

3. Do not use on PVC pipe.

- 4. Clean pipe surface thoroughly.
- 5. DO NOT use Vaseline ®, plumber's grease, or any other petroleum based product on seals or o-rings.
- 6. Mount saddle on pipe with outlet facing desired direction.

7. Tighten nuts evenly to a torque of 45-55 FOOT POUNDS.

- 8. After the corporation stop has been installed, recheck saddle torque and tighten if necessary.
- 9. A.Y. McDonald single strap saddles are designed to withstand water working pressure up to, but not exceeding, the working pressure rating of the pipe. Use only on a cold water service.
- 10. Saddle testing should be accomplished while services are exposed and prior to backfilling.

WARNING: Not for use in applications with frequent cyclic loading such as air blow off valves on water and sewer force mains. 3210-319 4/22



A.Y. McDonald Mfg. Co. Bronze Single Strap Saddle Instructions

- 1. Whenever possible, saddles should be installed after pipe pressure testing is completed.
- Make sure you have proper type and size of saddle 2. for pipe. Reference pipe diameter range, tap size and identification located on the top piece of each saddle.

3. Do not use on PVC pipe.

- 4. Clean pipe surface thoroughly.
- 5. DO NOT use Vaseline ®, plumber's grease, or any other petroleum based product on seals or o-rings.
- 6. Mount saddle on pipe with outlet facing desired direction.

7. Tighten nuts evenly to a torque of 45-55 FOOT POUNDS.

- After the corporation stop has been installed, recheck 8. saddle torque and tighten if necessary.
- 9. A.Y. McDonald single strap saddles are designed to withstand water working pressure up to, but not exceeding, the working pressure rating of the pipe. Use only on a cold water service.
- 10. Saddle testing should be accomplished while services are exposed and prior to backfilling.

WARNING: Not for use in applications with frequent cyclic loading such as air blow off valves on water and sewer force mains. 3210-319 4/22



- 1. Whenever possible, saddles should be installed after pipe pressure testing is completed.
- 2. Make sure you have proper type and size of saddle for pipe. Reference pipe diameter range, tap size and identification located on the top piece of each saddle.

3. Do not use on PVC pipe.

- 4. Clean pipe surface thoroughly.
- 5. DO NOT use Vaseline ®, plumber's grease, or any other petroleum based product on seals or o-rings.
- 6. Mount saddle on pipe with outlet facing desired direction.
- 7. Tighten nuts evenly to a torque of 45-55 FOOT POUNDS.
- 8. After the corporation stop has been installed, recheck saddle torque and tighten if necessary.
- 9. A.Y. McDonald single strap saddles are designed to withstand water working pressure up to, but not exceeding, the working pressure rating of the pipe. Use only on a cold water service.
- 10. Saddle testing should be accomplished while services are exposed and prior to backfilling.


WARNING: Not for use in applications with frequent cyclic loading such as air blow off valves on water and sewer force mains. 3210-319



Public Law 111-380

WARNING: It is unlawful in CALIFORNIA & VERMONT (effective 1/1/2010); MARYLAND (effective 1/1/2012); LOUISIANA (effective 1/1/2013) and the UNITED STATES OF AMERICA (effective 1/4/2014) to use any product in the installation or repair of any public water system or any plumbing in a facility or system that provides water for human consumption if the wetted surface area of the product has a weighted average lead content greater than 0.25%. This prohibition does not extend to service saddles used in California, Louisiana or under USA

WARNING: It is unlawful in CALIFORNIA & VERMONT (effective 1/1/2010); MARYLAND (effective 1/1/2012); LOUISIANA (effective 1/1/2013) and the UNITED STATES OF AMERICA (effective 1/4/2014) to use any product in the installation or repair of any public water system or any plumbing in a facility or system that provides water for human consumption if the wetted surface area of the product has a weighted average lead content greater than 0.25%. This prohibition does not extend to service saddles used in California, Louisiana or under USA Public Law 111-380.





A.Y. McDonald Mfg. Co. DUBUQUE, IA 52002

800-292-2737 | avmcdonald.com

3210-319

4/22 3210-319



A.Y. McDonald Mfg. Co. DUBUQUE, IA 52002

800-292-2737 | avmcdonald.com



A.Y. McDonald Mfg. Co. DUBUQUE, IA 52002 800-292-2737 | avmcdonald.com

3210-319

4/22

WARNING: It is unlawful in CALIFORNIA & VERMONT (effective 1/1/2010); MARYLAND (effective 1/1/2012); LOUISIANA (effective 1/1/2013) and the UNITED STATES OF AMERICA (effective 1/4/2014) to use any product in the installation or repair of any public water system or any plumbing in a facility or system that provides water for human consumption if the wetted surface area of the product has a weighted average lead content greater than 0.25%. This prohibition does not extend to service saddles used in California, Louisiana or under USA Public Law 111-380

WARNING: It is unlawful in CALIFORNIA & VERMONT (effective 1/1/2010); MARYLAND (effective 1/1/2012); LOUISIANA (effective 1/1/2013) and the UNITED STATES OF AMERICA (effective 1/4/2014) to use any product in the installation or repair of any public water system or any plumbing in a facility or system that provides water for human consumption if the wetted surface area of the product has a weighted average lead content greater than 0.25%. This prohibition does not extend to service saddles used in California, Louisiana or under USA Public Law 111-380.

WARNING: It is unlawful in CALIFORNIA & VERMONT (effective 1/1/2010); MARYLAND (effective 1/1/2012); LOUISIANA (effective 1/1/2013) and the UNITED STATES OF AMERICA (effective 1/4/2014) to use any product in the installation or repair of any public water system or any plumbing in a facility or system that provides water for human consumption if the wetted surface area of the product has a weighted average lead content greater than 0.25%. This prohibition does not extend to service saddles used in California, Louisiana or under USA Public Law 111-380.



A.Y. McDonald Mfg. Co. DUBUQUE, IA 52002 800-292-2737 | aymcdonald.com



A.Y. McDonald Mfg. Co. DUBUQUE, IA 52002 800-292-2737 | aymcdonald.com



A.Y. McDonald Mfg. Co. DUBUQUE, IA 52002 800-292-2737 | aymcdonald.com

4/22

3210-319

4/22