

(OVER)

3/22



IMPORTANT NOTICE - READ CAREFULLY

- 1. Keep valve clean and free from dirt and debris.
- 2. Protect valve from freezing, which may distort ball. In the event the valve does freeze, do not forcibly try to open or close the valve while the valve is frozen. This may destroy the valve.
- 3. Use a snug fitting smooth jaw wrench on the wrenching flat nearest the tightened end. Do not wrench the body/endpiece joint.
- Always use an approved sealant or teflon tape on tapered pipe threads.
- 5. If valve has compression style connection, read connection instruction sheet prior to installation.
- 6. If the valve cap or stop box handle is perpendicular to the water line, the valve is closed. If the valve cap or stop box handle is inline with the water line, the valve is open. For standard valves with turning restraints (checks), turn the cap counter-clockwise to open and clockwise to close (unless ordered otherwise). Valves without turning restraints (checks) may be turned either direction to open or close.
- 7. Ball valves generally require low operating torques. If valve turns hard, check turning direction before applying excess force. Excess force can damage or destroy the turning restraints (checks) in the ball valve cap and body assembly.
- 8. All valves must be operated in the fully opened or fully closed position. Attempts to throttle flow by operating the valve in a partially open position may destroy the valve.
- 9. PRESSURE TEST FOR LEAKS BEFORE BACKFILLING.

10. USE ONLY ON COLD WATER SERVICES.	
--------------------------------------	--

```
3210-335
                           800.292.2737 | sales@avmcdonald.com | avmcdonald.com
```



Installation Instructions

1. Keep valve clean and free from dirt and debris.

**Ball Valves** 

- 2. Protect valve from freezing, which may distort ball. In the event the valve does freeze, do not forcibly try to open or close the valve while the valve is frozen. This may destroy the valve.
- Use a snug fitting smooth jaw wrench on the wrenching flat nearest the tightened end. Do not wrench the 3. body/endpiece ioint.
- 4. Always use an approved sealant or teflon tape on tapered pipe threads.

**IMPORTANT NOTICE - READ CAREFULLY** 

- 5. If valve has compression style connection, read connection instruction sheet prior to installation.
- 6. If the valve cap or stop box handle is perpendicular to the water line, the valve is closed. If the valve cap or stop box handle is inline with the water line, the valve is open. For standard valves with turning restraints (checks), turn the cap counter-clockwise to open and clockwise to close (unless ordered otherwise). Valves without turning restraints (checks) may be turned either direction to open or close.
- 7. Ball valves generally require low operating torques. If valve turns hard, check turning direction before applying excess force. Excess force can damage or destroy the turning restraints (checks) in the ball valve cap and body assembly.
- All valves must be operated in the fully opened or fully closed position. Attempts to throttle flow by operating 8. the valve in a partially open position may destroy the valve.
- 9. PRESSURE TEST FOR LEAKS BEFORE BACKFILLING.

#### 10. USE ONLY ON COLD WATER SERVICES.

(OVER)



**IMPORTANT NOTICE - READ CAREFULLY** 

- 1. Keep valve clean and free from dirt and debris.
- 2. Protect valve from freezing, which may distort ball. In the event the valve does freeze, do not forcibly try to open or close the valve while the valve is frozen. This may destroy the valve.
- 3. Use a snug fitting smooth jaw wrench on the wrenching flat nearest the tightened end. Do not wrench the body/endpiece joint.
- Always use an approved sealant or teflon tape on tapered pipe threads.
- 5. If valve has compression style connection, read connection instruction sheet prior to installation.
- 6. If the valve cap or stop box handle is perpendicular to the water line, the valve is closed. If the valve cap or stop box handle is inline with the water line, the valve is open. For standard valves with turning restraints (checks), turn the cap counter-clockwise to open and clockwise to close (unless ordered otherwise). Valves without turning restraints (checks) may be turned either direction to open or close.
- 7. Ball valves generally require low operating torques. If valve turns hard, check turning direction before applying excess force. Excess force can damage or destroy the turning restraints (checks) in the ball valve cap and body assembly.
- 8. All valves must be operated in the fully opened or fully closed position. Attempts to throttle flow by operating the valve in a partially open position may destroy the valve.
- 9. PRESSURE TEST FOR LEAKS BEFORE BACKFILLING.

#### 10. USE ONLY ON COLD WATER SERVICES.

```
(OVER)
```

Installation Instructions

800.292.2737 | sales@avmcdonald.com | avmcdonald.com

```
3/22
```



3210-335

**IMPORTANT NOTICE - READ CAREFULLY Ball Valves** 

- 1. Keep valve clean and free from dirt and debris.
- 2. Protect valve from freezing, which may distort ball. In the event the valve does freeze, do not forcibly try to open or close the valve while the valve is frozen. This may destroy the valve.
- 3. Use a snug fitting smooth jaw wrench on the wrenching flat nearest the tightened end. Do not wrench the body/endpiece joint.
- 4. Always use an approved sealant or teflon tape on tapered pipe threads.
- 5. If valve has compression style connection, read connection instruction sheet prior to installation.
- 6. If the valve cap or stop box handle is perpendicular to the water line, the valve is closed. If the valve cap or stop box handle is inline with the water line, the valve is open. For standard valves with turning restraints (checks), turn the cap counter-clockwise to open and clockwise to close (unless ordered otherwise). Valves without turning restraints (checks) may be turned either direction to open or close.
- 7. Ball valves generally require low operating torques. If valve turns hard, check turning direction before applying excess force. Excess force can damage or destroy the turning restraints (checks) in the ball valve cap and body assembly.
- 8. All valves must be operated in the fully opened or fully closed position. Attempts to throttle flow by operating the valve in a partially open position may destroy the valve.

#### PRESSURE TEST FOR LEAKS BEFORE BACKFILLING.

#### 10. USE ONLY ON COLD WATER SERVICES.

3210-335



IMPORTANT NOTICE - READ CAREFULLY **Ball Valves** 

A.Y. McDonald waterworks products are designed for reliable service. Like all brass products, however, they can be damaged by improper handling and use.

## CAUTIONS

- 1. Protect threads. Avoid loose fitting wrenches. Do not drop or impact.
- 2. Use extra care with high water pressures (over 100 PSIG) and pipe or tubing over 1". Consult factory if desired.
- 3. Inspect and test all joints, valves and fittings before backfilling.
- 4. Backfill carefully so as to avoid damage to the service line and connections. Looping of the service lines is recommended to minimize strain.
- 5. DO NOT use Vaseline  $\ensuremath{\mathbb{R}}$ , plumber's grease, or any other petroleum based product on seals or o-rings.

#### Damage caused by improper use and/or handling will void our warranty

(OVER)

3/22

WARNING: It is unlawful in CALIFORNIA & VERMONT (effective 1/1/2010); MARYLAND (effective 1/1/2012); LOUISIANA (effective 1/1/2013) and the UNITED STATES OF AMERICA (effective 1/4/2014) to use any product in the installation or repair of any public water system or any plumbing in a facility or system that provides water for human consumption if the wetted surface area of the product has a weighted average lead content greater than 0.25%. This prohibition does not extend to service saddles used in California, Louisiana or under USA Public Law 111-380.

3210-335	800.292.2737	sales@aymcdonald.com	aymcdonald.com



## IMPORTANT NOTICE - READ CAREFULLY

Installation Instructions

A.Y. McDonald waterworks products are designed for reliable service. Like all brass products, however, they can be damaged by improper handling and use.

## CAUTIONS

- 1. Protect threads. Avoid loose fitting wrenches. Do not drop or impact.
- 2. Use extra care with high water pressures (over 100 PSIG) and pipe or tubing over 1". Consult factory if desired.
- 3. Inspect and test all joints, valves and fittings before backfilling.
- 4. Backfill carefully so as to avoid damage to the service line and connections. Looping of the service lines is recommended to minimize strain.
- $\hbox{5. DO NOT use Vaseline} \ensuremath{\textcircled{B}}, \ensuremath{\text{plumber's grease, or any other petroleum based product on seals or o-rings.} \ensuremath{}$

## Damage caused by improper use and/or handling will void our warranty

(OVER)

3/22

WARNING: It is unlawful in CALIFORNIA & VERMONT (effective 1/1/2010); MARYLAND (effective 1/1/2012); LOUISIANA (effective 1/1/2013) and the UNITED STATES of AMERICA (effective 1/4/2014) to use any product in the installation or repair of any public water system or any plumbing in a facility or system that provides water for human consumption if the wetted surface area of the product has a weighted average lead content greater than 0.25%. This prohibition does not extend to service saddles used in California, Louisiana or under USA Public Law 111-380.



# IMPORTANT NOTICE - READ CAREFULLY Ball Valves

#### A.Y. McDonald waterworks products are designed for reliable service. Like all brass products, however, they can be damaged by improper handling and use.

## CAUTIONS

- 1. Protect threads. Avoid loose fitting wrenches. Do not drop or impact.
- Use extra care with high water pressures (over 100 PSIG) and pipe or tubing over 1". Consult factory if desired.
- 3. Inspect and test all joints, valves and fittings before backfilling
- 4. Backfill carefully so as to avoid damage to the service line and connections. Looping of the service lines is recommended to minimize strain.
- 5. DO NOT use Vaseline  $\ensuremath{\mathbb{R}}$ , plumber's grease, or any other petroleum based product on seals or o-rings.

### Damage caused by improper use and/or handling will void our warranty

(OVER)

WARNING: It is unlawful in CALIFORNIA & VERMONT (effective 1/1/2010); MARYLAND (effective 1/1/2012); LOUISIANA (effective 1/1/2013) and the UNITED STATES OF AMERICA (effective 1/4/2014) to use any product in the installation or repair of any public water system or any plumbing in a facility or system that provides water for human consumption if the wetted surface area of the product has a weighted average lead content greater than 0.25%. This prohibition does not extend to service saddles used in California, Louisiana or under USA Public Law 111-380.

800.292.2737 | sales@aymcdonald.com | aymcdonald.com

3/22



3210-335

IMPORTANT NOTICE - READ CAREFULLY

Installation Instructions

#### A.Y. McDonald waterworks products are designed for reliable service. Like all brass products, however, they can be damaged by improper handling and use.

## CAUTIONS

- 1. Protect threads. Avoid loose fitting wrenches. Do not drop or impact.
- Use extra care with high water pressures (over 100 PSIG) and pipe or tubing over 1". Consult factory if desired.
- 3. Inspect and test all joints, valves and fittings before backfilling.
- 4. Backfill carefully so as to avoid damage to the service line and connections. Looping of the service lines is recommended to minimize strain.
- $5. \ \ \mathsf{DO}\ \mathsf{NOT}\ \mathsf{use}\ \mathsf{Vaseline}{}^{\textcircled{}}_{\textcircled{}},\ \mathsf{plumber's}\ \mathsf{grease,}\ \mathsf{or}\ \mathsf{any}\ \mathsf{other}\ \mathsf{petroleum}\ \mathsf{based}\ \mathsf{product}\ \mathsf{on}\ \mathsf{seals}\ \mathsf{or}\ \mathsf{o-rings}.$

#### Damage caused by improper use and/or handling will void our warranty

WARNING: It is unlawful in CALIFORNIA & VERMONT (effective 1/1/2010); MARYLAND (effective 1/1/2012); LOUISIANA (effective 1/1/2013) and the UNITED STATES OF AMERICA (effective 1/4/2014) to use any product in the installation or repair of any public water system or any plumbing in a facility or system that provides water for human consumption if the wetted surface area of the product has a weighted average lead content greater than 0.25%. This prohibition does not extend to service saddles used in California, Louisiana or under USA Public Law 111-380.

3210-335